

Rec Center Game Clock Directions

To Start Game Clock:

- (1) Press **Set Time**
- (2) Punch in time using keypad on right
- (3) Press **Enter**
- (4) Press **Start**

To Stop Clock:


Press **Stop**

To Clear Clock:






- (1) Press **Set Time**
- (2) Press **Clear Entry**
- (3) Press **Enter**

To Set Period:

- (1) Press **Period**
- (2) Punch in Number
- (3) Press Enter on Keypad



Between Periods Use These



Enter

Clear Entry

To Set Penalty:

- (1) Press appropriate **set penalty time** (Home or Visitor and 1st or 2nd player in the box)
- (2) Punch in 130 for 1minute 30 seconds.
- (3) Press **Enter**

When penalty runs out, a zero will remain. To clear the zero:

- (1) Press **set penalty time**
- (2) Press **clear entry**
- (3) Press **enter**

Remember – if you mess up, press the appropriate “Set Button,” “Clear Entry” and “Enter.”

