



NEVCO Model 871 Scoreboard Quick Reference




Model Code 871
Hockey



Getting Started

ON / OFF SWITCH—right side of unit

DO YOU WANT TO START WHERE
TURNED OFF LAST?



ENTER MODEL NUMBER



DO YOU WANT TO USE
PENALTY TIME OUT?



Times

WARM-UP: 3 minutes, start clock when officials are on the ice, nets in place, players go on ice.

SQUIRT: 12 minute periods

PEE-WEE: 15 minute periods

BANTAM: 15 minute periods

MIDGET: 17 minute periods

Setting Warmup and Period Time

Warmup or Period time,
include leading zero for under
10 minutes (e.g 0300 warmup)

PRESS



PRESS



PRESS



ENTER PERIOD



USE ATTACHED SWITCH TO START AND STOP CLOCK

Intermissions: 1 minute (15 minutes when resurfacing)
Between games: 12 minutes



NEVCO Model 871 Scoreboard Quick Reference

ENTERING SCORES

ADD ONE TO EXISTING SCORE




ENTER ACTUAL SCORE (this method replaces whatever current score is displaying)




PENALTIES

ENTER PENALTIES



****NOTE:** only two penalties per team will display on the scoreboard. **HOWEVER,** if there are more than two, enter them following the same instructions. As the older penalties expire, the other ones will display.

EDITING PENALTIES



ENTER LENGTH OF PENALTY

- Minor/Major/Misconduct
 10U: 1 min/3 min/6 min
 12U: 1:30 min/4 min/8 min
 14U: 1:30 min/4 min/8 min
 18U: 2 min/5 min/10 min

CLEAR PENALTIES (after recording power play goal)

