

UPLOAD YOUR RECORDING: VEO CAM 3

Your Veo Cam 3 will automatically start uploading stored recordings as soon as it's connected to the internet.

Connectivity Options

To ensure a smooth process, you have two options:

- WiFi: you can go wireless and connect the Veo Cam 3 to the internet via WiFi. Here's how [How to connect your Veo Cam 3 to WiFi](#). You only need to connect to a WiFi once, then it will be saved and remembered by the camera.
- Ethernet cable: you can go the more traditional way and connect your camera to the internet using an ethernet cable and a done adaptor. Keep in mind these are not included with your camera.

Track your upload

If you want to track the progress of your upload, you can do so by connecting to the Veo Camera app and accessing the Library.

In the Library you will find the uploading recording under **On Camera**. You might need to refresh the page by swiping down.

When the camera is uploading, the first and second status lights on the back of the camera will blink, letting you know everything is going well.