

TO SET THE PERIOD:

1. Press the "*PERIOD*" key and the number of the period "1", "2" or "3", and "ENTER".

TO SET PENALTIES:

1. Press "*ENABLE PENALTY CLOCK*" key before you set the first penalty of the game. You only have to do this once & it will work for the whole game.

TO ADD PENALTIES:

1. On the "HOME" or "VISITOR" side, press the "*PLAYER PENALTY*" key.
2. Press "ENTER".
3. Type the player number (ex: 02)
4. Press "ENTER".
5. Type the penalty time.
6. Press "ENTER".

TO DELETE PENALTIES:

1. Press on the "HOME" or "VISITOR" side the "*PLAYER PENALTY*" key.
2. Press the " \triangle " key located by the "MENU" key until the penalty that you want to clear is showing on the LCD display.
3. Press the "CLEAR" button.
4. Press "ENTER".

WEST MEADOWS & SPORTS COMPLEX

SCOREBOARD INSTRUCTIONS

TO START THE SCOREBOARD IN ICE HOCKEY MODE:

1. Turn the switch located on the back of the control panel to "on".
2. The LCD display should read "RESUME GAME?" If it does not, turn the switch off and then back on.
3. When asked if you want to "RESUME GAME?" answer "NO" (clear key).
4. The LCD will now display "ENTER CODE".
5. If the code "063" is not the code on the display, type "063" and "ENTER".
6. The LCD will now say "1/10 SECOND?"
7. Press "YES" (enter key). You are now in Ice Hockey Mode.

TO SET THE TIME:

1. Press "SET MAIN CLOCK" button.
2. Enter the number of minutes you want. (For example, 11 minutes by pressing "11000")
3. Press "ENTER"
4. To turn the time ON and OFF use the switch connected to the scoreboard.

TO SET THE SCORE:

1. To get the score to "zero", to start, press the "SCORE" key on the "HOME" or "VISITOR" side. Then press "0" and "ENTER".
2. When a goal is scored press the "SCORE+1" key on the "HOME" or "VISITOR" side.